



Installation guide

1. Place box on roofrack bars.
2. Open box by turning key and lifting lid.
3. Position factory bars to center box on vehicle if possible. Make sure to line them up with the holes in the box.
4. Ensure that box clears roof antennas and rear hatches (where applicable).
5. Note which hole in the underbar plate is used for your bars and make sure it fits with the opening of the trunk.
6. Tighten all knobs firmly and make sure that the assembly screws are well inserted in the slot of the plate.
7. Total load permissible is determined by the limit of the factory rack. The total weight is the weight of the cargo plus the weight of the box.
8. Close and lock the box. **WARNING.** Ensure that the box is **ALWAYS** locked to avoid.